









RFID WRITER Instructions AT-RFID-V2.0



Button Functions & Setup

Icon	Label	Function	LED Indicator(first 2 digits)	Tips
	1	Selection on: P1	P100	
	2a	Video number up	P101,P102,....P199	Press button 2a when LED is P1XX
	2b	Video number down	P101,P102,....P199	Press button 2b when LED is P1XX
	3a	To Write a number to multiply tags via placing one tag per time	P101,P102,....P199	Press 3a when when LED is P1XX
	3b	One time writing, One Tag	P101,P102,....P199	Press 3b when LED is P1xx
	1+3a	Tag reader mode to check the written tag is correct	LC	when it is P100, press 1 and then press 3a
	3a	To erase the written tags	PC00	When it is P100, press 3a to go to data erasing mode

Writing Area

	Data Writing Area, Place the RFID tag here and press 3a or 3b to write the tag data	Tips: When LED is P1XX
---	---	------------------------

Notes: The RFID tag numbers are written into numbers 00,01,02,....10,12....98,99, to work as event trigger with video files 00.avi,01.avi,02.avi....99.avi, please keep the tag number and video file name matched.